

OLYMPUS®

IS-2DLX

■ INSTRUCTIONS

- Before using your IS-2DLX, read this manual carefully to ensure correct use.
- We recommend that you take test shots to get accustomed to your IS-2DLX before taking important photographs.

ADDITIONAL
FUNCTIONS

TAKING BETTER
PICTURES

CAMERA
MAINTENANCE


Thank you for purchasing the Olympus IS-2DLX.

MAIN FEATURES

- Built-in 35mm ~ 135mm approx. 4X zoom lens for increased shooting range.
- Full-fledged macro functions include Zoom Macro for subjects as close as 0.6 m (2 ft), Super Macro for subjects as close as 0.39 m (1.3 ft), and 1:1 Macro* which captures life-size images of small subjects on film.
- ED (extraordinary dispersion) glass is used in the lens, achieving crisp, clear images with high contrast.
- The standard shooting mode lets anyone take beautiful pictures easily.
- Panorama photographs are possible when the optional panorama adapter is attached.
- Other various easy-to-use functions include versatile flash, subject, drive, and exposure modes and more.

* The optional IS/L LENS A-LIFE SIZE MACRO H.Q. CONVERTER $f=13\text{cm}$ is required.

Symbols used in this manual:



PREPARATIONS	Names and functions of parts	4	Checking the batteries	9
	Viewfinder display/LCD panel	6	Points to remember	10
	Attaching the strap	7	Reset operation	12
	Loading the batteries	8		

BASIC OPERATIONS	Loading the film	13		
	Taking pictures	16		
	Unloading the film	19		

ADDITIONAL FUNCTIONS	Using the focus lock	20	Using the drive modes	38
	Flash photography	21	Using the exposure modes	43
	Selftimer	27	Exposure compensation	49
	Macro photography	29	PF (power focus)	50
	Using the subject modes	32	Spot metering	51

TAKING BETTER PICTURES	Flash	52	Exposure compensation	62
	Effects of zoom and its advantages	55	Film speed	62
	Autofocus (AF)	57	Macro photography	63
	Exposure	59	Panorama photography	66
	Metering the amount of light	61	Accessories	67

CAMERA MAINTENANCE	Care and storage	68		
	Battery handling	69		
	Troubleshooting	70		
	Questions and answers	73		
	Specifications	74		

NAMES AND FUNCTIONS OF PARTS

Hot shoe cover

Shift buttons

Selects the exposure compensation level, aperture setting and shutter speed.

Shutter release button

AF illuminator

Also blinks when the selftimer is activated.

Power ON/OFF switch

Flash

Flash release (See p. 21.)


Strap attachment stud

Zoom (T/W) buttons

(See p. 17.)

Become the focus buttons in the PF mode.





Viewfinder
(See p. 6.)

Spot button
(See p. 51.)

PF button
Flash mode button*

Film window
For confirmation of
film ISO speed

Selftimer button
Drive mode button*

Back cover
release

+/- button
Exposure mode button*

Remote cord
jack
For connecting to
the optional
M-Remote Cord
1.2m or 5m

Macro button
Subject mode button*

Battery
compartment
cover

Mid-roll rewind button

Tripod socket

Date MODE, SET and
ADJUST buttons

Function button (See p. 22/32/38/43.)
Switches to the modes indicated by *.

Reset button
Restores the standard shooting mode and
checks the battery condition.


VIEWFINDER DISPLAY/LCD PANEL

VIEWFINDER DISPLAY

Spot frame
Autofocus frame

Flash

Panorama marks*
*Optional IS/L PANORAMA ADAPTER is required.




Autofocus
Macro
Shutter speed
Aperture setting
Spot metering
Exposure compensation/
Manual exposure

LCD PANEL

Aperture setting/1:1 Macro* information
Displays the aperture setting except when in the 1:1 Macro mode, in which the correct working distance is displayed.

1:1 Macro adjustment mark*


Shutter speed
Selftimer
Single-frame advance
Continuous-frame advance
Double exposure
Program auto-exposure
Exposure compensation indicator
Aperture-preferred auto-exposure
Manual exposure
Exposure counter/Exposure compensation level
Date-time indicator



Battery check
Manual flash
Power focus (autofocus override)
Spot metering
Auto flash
Auto-S flash
Fill-in flash
Sports mode
Portrait mode
Night scene
1:1 Macro*
Super Macro
Single-frame advance
ESP metering

* The optional IS/L LENS A-LIFE SIZE MACRO H.Q. CONVERTER f=13cm is required in the 1:1

ATTACHING THE STRAP




- 1 Put the strap mount into the guide hole.
- 2 Push the strap mount onto the camera's strap attachment stud, and pull it to adjust the strap's length.

LOADING THE BATTERIES


Use two 3V lithium batteries (CR123A or DL123A).

1. Turn the lock screw on the bottom of the camera counter-clockwise to open the battery cover.



- The types of batteries that can be used are also shown inside the battery cover.


2. Insert the batteries as shown and replace the cover, turning the lock screw clockwise.




- Read "Battery Handling" on page 69.

CHECKING THE BATTERIES

1. Turn the power switch ON.



2. Press the reset button to check the batteries.



	Batteries are OK. The mark disappears when the finger is released from the button.
 Blinks	Batteries are low. Have spares handy.
 Lights	Batteries should be replaced immediately.

POINTS TO REMEMBER

Hold the Camera Correctly.



Correct.



Correct.



Incorrect.


Note: As the focal length becomes larger, shaking the camera becomes more noticeable. Hold the camera firmly with both hands to keep from shaking the camera.

Caution:
Keep your fingers away from the lens, AF illuminator and flash.

Proper Shutter Release.


Practice before loading the film.

1. Depress The shutter release button halfway.



To lock the focus.

2. Depress the shutter release button fully.



To release the shutter and take the picture.

Note: When the autofocus indicator doesn't light, the shutter won't release.
(See p. 57)

Cautions:

- Press the shutter release button gently
- Avoid shaking the camera when pressing the shutter release button to prevent blurry pictures.

Make sure


The image is clear and the autofocus indicator lights in the viewfinder.

RESET OPERATION

Reset operation restores the standard shooting mode, for worry-free photography that anyone can perform. Also use this mode when you don't know what operation to perform.

Press the reset button.

Standard Shooting Mode




Exposure mode: Program Auto (P)
Drive mode; Single (S)*
Light metering mode: ESP
Flash mode: AUTO or AUTO-S
Exposure compensation: ± 0
Focusing: AF

The camera will return to the standard shooting mode, and other set modes will be canceled.


* Won't be restored when the reset button is pressed after the first shot has been taken in the Double Exposure mode. (See p. 41)

LOADING THE FILM

1. Slide the back cover release upward to open the back cover.





2. Insert the film cartridge.




Note: Use DX-coded film.
Caution: Do not touch the shutter curtain when loading.

3. Pass the edge of the film under the film guide, and align the film leader with the film loading indicator.




Note: Make sure the film is lying flat. If not, push the cartridge down.

4. Close the back cover.



The film automatically advances to the first frame.

5. Turn the power switch ON.



Make sure


The exposure counter on the LCD panel reads 1.

Note: If **E** blinks in the exposure counter, reload the film.

TAKING PICTURES

Follow the procedure here to cover ordinary photography.

1. Remove the lens cap, and turn the power switch ON.



2. While looking through the viewfinder, press the zoom button to determine the composition.



Make sure The lens advances, and the LCD panel lights.


Note: If no operation is made for approx. 30 seconds, the LCD panel goes out and will come on again when the operation is resumed.

How to Use the Zoom Buttons

Telephoto: Press the **T** button to zoom in.




Max. telephoto focal length: 135mm



Wide-angle: Press the **W** button to zoom out.



Max. wide-angle focal length: 35 mm



3. Position your subject within the autofocus frame.



Autofocus frame

4. Depress the shutter release button halfway.



Make sure The autofocus indicator lights when the subject is in focus. It will blink if the subject is difficult for the autofocus to lock on, and when the subject is too close.

Note: When the autofocus indicator doesn't light, the shutter won't release. (See p. 57.)

5. Depress the shutter release button fully to take the picture. The film automatically advances to the next frame.



Working Distance

Standard shooting (39mm~135mm): 1.2 m (3.91) ~ ∞.


Macro shooting as close as 0.6 m (2 ft) is possible through the 35mm~100mm focal length (Zoom Macro).

UNLOADING THE FILM


The camera automatically rewinds the film when you reach the end of a roll.

Make sure the motor has stopped and the Σ is blinking on the LCD panel, before opening the back cover and removing the film.

Rewinding the film before the end of the roll



- If the power is turned OFF while rewinding, operations will stop. Rewind mode however, is not canceled. Rewinding will continue when the power switch is turned ON again.
- The final number of exposures may sometimes exceed the number of exposures specified on the film.



Press the mid-roll rewind button with the tip of a ballpoint pen, or the like. Do not use an instrument with a sharp tip.

USING THE FOCUS LOCK

To avoid taking out-of-focus pictures

When the main subject is not in the center of the Autofocus frame, use the focus lock.

1. Position the autofocus frame on your subject and press the shutter release button halfway.



Make sure

The autofocus indicator lights in the viewfinder.

Autofocus frame

2. Reposition your subjects in the picture frame while keeping the shutter release button depressed halfway. Then press the shutter release button fully.



Notes:

- When the focus is locked, the exposure is also locked (AE lock).
- The focus cannot be locked using the M-Remote Cord.

FLASH PHOTOGRAPHY

This camera has two flash tubes that are automatically selected and fired according to the shooting conditions. There are also various flash modes that can be selected to match your needs.

Flash Modes


Mode	Function
AUTO	Automatically fires in low-light conditions. (p. 23)
AUTO-S	Significantly reduces the phenomenon of "red-eye" (when a subject's eyes appear red). (p. 25)
FILL-IN	Fires regardless of available light. (p. 26)

Notes:

- See p. 36 for the Night Scene mode and p. 48 for the Manual Flash mode.
- When the reset button is pressed in the Fill-In mode, the Auto Flash mode will be restored.


How to Select the Flash Mode

1. Slide the flash release to flip up the flash.



Note: Always be sure to use the flash release to flip up the flash.


2. Use the function and flash mode buttons to select the mode.



Make sure

When the function button ❶ is pressed, the mode selected by using the flash mode button ❷ starts blinking.

3. Press the function button to engage the mode.



Make sure

The engaged mode is blinking.
Note: The blinking indication's mode can also be engaged directly by pressing the shutter release button.


⚡ AUTO (Auto Flash Mode)

The flash fires automatically when there is insufficient light. Use this mode normally.

1. When ⚡ blinks in the viewfinder, the flash should be used. Slide the flash release.



2. When the flash is flipped up, the camera will start recharging the flash.



Make sure ⚡ AUTO lights. When the flash is recharged, ⚡ in the viewfinder will light.

Note: The flash won't fire until recharging is finished.

3. Press the shutter release button.



Auto Flash Range*

(with color negative film)

Focal length	35mm	135mm
ISO 100	4.6m (15.1 ft)	5 m (16.4 ft)
ISO 200	6.5m (21.3ft)	7.1 m (23.3 ft)
ISO 400	9.2 m (30.2 ft)	10 m (32.8 ft)

* The Auto Flash mode can be combined with the Zoom Macro or Super Macro mode.


Notes:

- The shutter speed is automatically set at 1/100-sec. when the flash fires. If the subject requires a faster shutter speed, the flash won't fire.
- If the subject is too far, the shutter speed and aperture indicator will blink in the viewfinder when the shutter release button is depressed halfway. In this case, the picture should be taken at a shorter distance.

AUTO-S (Red-Eye Reducing Flash)

Approximately 20 pre-flashes are emitted before the main flash fires, significantly reducing the phenomenon of "red-eye" (when a subject's eyes appear red). This mode is the same as Auto Flash except for the pre-flashes.

1. Flip up the flash, and select the Auto-S mode.



Notes:


- After pressing the shutter release button, hold the camera securely until the shutter has been released.
- To cancel the Auto-S mode, select another mode following the procedure on page 21.

FILL-IN (Forced Activation)


In this mode, the flash always fires, Even in backlighting, both the subject and background can be shot clearly. And portraits look lively by reflecting light into the subject's eyes,

1. Make sure the exposure mode is set to P (program).

2. Flip up the flash, and select the FILL-IN Flash mode by using the flash mode button.



Note: To cancel the subject mode, press the reset button (see p. 12),




Note: The shutter speed is automatically set at 1/100-sec.

SELFTIMER

To put yourself in the picture

1. Press the selftimer button.
☺ is displayed on the LCD panel.



2. Position the autofocus frame on the subject. Press the shutter release button half-way to focus on the subject,



The focus and exposure will be locked.

3. Press the shutter release button fully to activate the selftimer.



The shutter will be released
12 seconds later.

Make sure

The viewfinder display disappears and the AF illuminator and  blink.

Notes:

- Use a tripod, etc., to hold the camera steady.
- The selftimer will be automatically canceled after the shot.
- To cancel the selftimer in the middle of operation, press the selftimer button again.

Important:

To prevent backlight from entering through the viewfinder, do not move your eye from the viewfinder.

MACRO PHOTOGRAPHY

Macro (Close-up) Modes

Zoom Macro	Working distance: 0.6 m (2 ft) ~ ∞ (Focal length: 35mm ~ 100mm)
Super Macro	Working distance: 0.39 m (1.3 ft) ~ ∞ (Focal length: 70 mm)
1:1 Macro	Full scale on the film


(See p. 65)

Notes:

- When the subject is closer than 1.2 m (4 ft), the subject may not be in focus even though the AF illuminator lights.
- In the Super Macro and 1:1 Macro modes, the optional Electronic Flash G40 does not fire except when in the Manual Exposure mode.

Zoom Macro

1. Press the zoom button to ensure that the front edge of the camera body (A) is within the MACRO (0.6 m) range indicated on the lens barrel.



Note: When you focus on a subject closer than 1.2 m (4 ft),  will light in the viewfinder.

Super Macro

An area of approximately 12 X 18 cm (4-3/4 X 7-1/16 in) will fill the entire frame, Press the macro button,  is displayed on the LCD panel, The lens is then set at 70mm Shoot from as close as 0,39 m (1.3 ft) to the subject,



Make sure

 lights in the view/finder.

Note: In the Super Macro mode, zoom does not operate. To cancel the Super Macro mode, press the macro button again.


1:1 Macro*

Life-size images of small subjects can be captured on film.

Mount the optional converter, and

1. press the macro and function buttons simultaneously.

* The optional IS/L LENS A-LIFE SIZE MACRO H.Q. CONVERTER f = 13 cm is required. (Refer to p. 64.)




Make sure

 1:1 converter on the LCD panel and  in the viewfinder are blinking.

Note: To cancel the 1:1 Macro mode, press the macro and function buttons simultaneously, or press the reset button.

2. The correct 1:1 Macro distance will be displayed on the LCD panel,  or  will also appear to check if the subject can be focused in the present position.



Checking the 1:1 Macro Distance

 Lights	The current distance is correct. The subject can be focused in the present position.
 Blinks	The current distance is incorrect. The subject cannot be focused in the present position. Move the camera according to the 1:1 Macro distance displayed on the LCD panel.

Note: When the shutter release button is pressed, the 1:1 Macro distance on the LCD panel will disappear, and the shutter speed and aperture setting will be displayed in the standard shooting mode. Press the macro button again to display the 1:1 Macro distance.

Important: Use of the flash is recommended, because a fast shutter speed will prevent the picture from being affected by the camera shaking.

USING THE SUBJECT MODES


There are three subject modes for optimal results when taking pictures of various subjects.

Subject Modes

Display	Function
	Sports To shoot fast-moving subjects. (p. 34)
	Portrait To take pictures with blurred backgrounds for a "portrait" effect. (p. 35)
	Night Scene To shoot night scenes or night scenes with subjects in the foreground. (p. 36)

How to Select the Subject Mode


1. Press the function button.



Make sure

The three subject mode indicators all appear.


2. Press the subject button to select the mode.



Make sure

The selected subject mode is blinking.
Note: The Program Auto-exposure mode will be engaged, and the correct drive and flash modes will be selected.

3. Press the function button again to engage the mode.



Make sure

The selected subject mode lights.
Note: The blinking indication's mode can also be engaged directly by pressing the shutter release button.

SPORTS

To shoot fast-moving subjects.

In this mode, the camera automatically selects both a faster shutter speed and the Continuous Shooting mode. This results in increased clarity, and lets you capture fast moving photo opportunities you might otherwise miss.

1. Select the Sports mode to display  on the LCD panel.



2. As long as the shutter release button is pressed, the shutter will release continuously,



Notes:


- Auto-S flash cannot be used in the Sports mode.
- The camera exposes a maximum of two frames per second.

PORTRAIT

To take pictures with blurred backgrounds for a "portrait" effect.

Portrait mode lets you take beautiful portrait photographs, This is especially effective when the lens is at the telephoto setting.

1. Select the Portrait mode to display  on the LCD panel.



Note: The aperture is wide open.

2. Press the shutter release button .




NIGHT SCENE

To shoot night scenes or night scenes with subjects in the foreground

In this mode, the camera automatically selects the ideal exposure compensation for shooting night scenes free of subjects, and for shooting night scenes with subjects in the foreground.

Shooting Night Scenes Free of Subjects

1. Select the Night Scene mode to display  on the LCD panel.
2. Press the shutter release button.



Shooting Night Scenes with Subjects in the Foreground (Slow-Synchro)

Engage the Night Scene mode. Flip up the flash. Press the shutter release button.



Both the subject and background will be perfectly exposed.

Note: Since a slow shutter speed is automatically selected in low-light situations, the use of a tripod is recommended to prevent blurred pictures caused by shaking the camera.

Shutter speeds in the Night Scene mode: Wide-angle: 3 sec. max. Telephoto: 4 sec. max. (With negative color film, ISO 100)

With Auto Flash




In the Auto Flash mode, only the subject in the foreground can be shot.

USING THE DRIVE MODES


There are two film-advance modes in addition to the standard single-frame advance mode.

Drive Modes


Display	Function
	Single Standard single-frame advance mode
	Continuous Shooting The camera releases the shutter continuously while keeping moving subjects in focus and correctly exposed. (p. 40)
	Double Exposure You can combine two images on a single frame. (p. 41)

Selecting the Drive Mode

1. Press the function button.



2. Press the drive mode button to select the mode.



Make sure The selected drive mode is blinking.

3. Press the function button to engage the mode.




Make sure The selected drive mode lights.

Note: The blinking indication's mode can also be engaged directly by pressing the shutter release button.

CONTINUOUS SHOOTING

The camera releases the shutter continuously while keeping moving subjects in focus and correctly exposed.

1. Select the Continuous Shooting mode to display **C** on the LCD panel.



2. While the shutter release button is fully pressed, the shutter releases continuously.




Notes:

- The camera exposes a maximum of approximately 2 frames per second.
- When used in combination with the flash, the flash may not fire after the second frame. The exposure will be adjusted automatically instead.

DOUBLE EXPOSURE

You can expose two images on a single frame.

1. Select the Double Exposure mode to display D.EXP on the LCD panel.
2. Press the shutter release button fully to take the first exposure.



D.EXP on the LCD panel will blink.
The film will not be advanced.

3. Take the second exposure.
The film will advance, and
the Double Exposure
mode will be canceled.



Note: The Double Exposure mode cannot be canceled after the first shot.


USING THE EXPOSURE MODES

Exposure Modes


Display	Function
P	Program Auto (ESP metering) Both the aperture and shutter speed are set automatically. Standard exposure mode for ordinary shooting.
A	Aperture-Preferred Auto (center-weighted average metering) The aperture is set manually, and the camera automatically controls the correct shutter speed. (p. 45)
M	Manual Exposure (center-weighted average metering) Both the aperture and shutter speed are set manually. (p. 46)

Selecting the Exposure Mode

1. Press the function button.




2. Press the exposure mode button to select the mode.



Make sure The selected exposure mode is blinking.

3. Press the function button to engage the mode.



Make sure The selected exposure mode lights.

Note: The blinking indication's mode can also be engaged directly by pressing the shutter release button.

APERTURE-PREFERRED AUTO

Auto-exposure photography can be performed to control background blur.


1. Enter the Aperture-Preferred Auto mode. Press the shift buttons to adjust the aperture setting.

Note: Larger aperture settings such as F5.6 will often give a blurred background, and smaller aperture settings such as F22 will give a sharper background.




F5.6

F22




MANUAL EXPOSURE


1. Select the Manual Exposure mode to display M on the LCD panel.




2. Press the shift button to adjust the aperture.



3. While pressing the +/- button, press the shift-button to adjust the shutter speed.




4. The exposure level will be displayed on the LCD panel and in the viewfinder.



- + Blinks: Overexposed
- + Lights: Slightly overexposed
- ± Lights: Correctly exposed
- Lights: Slightly underexposed
- Blinks: Underexposed

Flash Photography in the Manual Exposure Mode

1. Flip up the flash, and set the shutter speed to 1/100-sec. or slower.



2. Set the aperture setting according to the camera-to-subject distance in the table below.

Aperture setting (color negative film)

	Super Macro	Zoom Macro			Standard				
Distance	0.39~ 0.6m	0.6~ 0.8m	0.8~ 1m	1~ 1.2m	1.2~ 1.5m	1.5~ 2m	2~ 2.5m	2.5~ 3.2m	3.2~ 4m
	1.3~ 2.0ft	2.0~ 2.6ft	2.6~ 3.3ft	3.3~ 3.9ft	3.9~ 4.9ft	4.9~ 6.6ft	6.6~ 8.2ft	8.2~ 10.5ft	10.5~ 13.1ft
ISO 50	F22	F16	F11	F9.5	F8	F5.6	F4.5		
ISO 100		F22	F16	F13	F11	F8	F6.7	F5.6	F4.5
ISO 200			F22	F19	F16	F11	F9.5	F8	F5.6
ISO 400		-		-	F22	F16	F13	F11	F8


Calculation formula for ISO 100: Aperture setting = GN15 ÷ Distance (m)
Aperture setting = GN50 ÷ Distance (ft)

Note: Will a shutter speed faster than 1/100-sec, the flash will not fire.

EXPOSURE COMPENSATION

The exposure compensation levels can be set up to $\pm 4\text{EV}$ in $1/3\text{EV}$ steps.

1. While pressing the +/- button, press the shift button to set the desired compensation level.



Make sure The exposure level is displayed in the viewfinder and on the LCD panel.

Note: While pressing the +/- button, the exposure counter changes to the compensation level display.

+2EV



$\pm 0\text{EV}$




-2EV



PF (Power Focus)

When the distance at which you want to shoot is predetermined, you can set the focus in advance and wait until the photo opportunity comes.

1. Focus on the subject by using autofocus first. Then press the PF button to display **PF** on the LCD panel.
2. Press the shutter release button to take a picture.



Note: Zooming cannot be performed in the PF mode. To cancel the PF mode, press the PF button again.




Notes:

- The focus is fixed even after the finger is released from the shutter release button.
- Manual focusing is possible using the zoom button. Use it when autofocusing is difficult (see p. 57).

SPOT METERING

In this mode, the camera limits light metering to the subject's particular area such as a face and sets the correct exposure.

1. Position the subject for spot metering within the spot frame, and press the SPOT button.



(Make sure)  will be displayed on the LCD panel and in the viewfinder, and the exposure is locked.

2. Recompose the shot, then press the shutter release button to take the picture.



Notes:

- When the flash is flipped up, the camera does not perform spot metering.
- After the shot, the Spot Metering mode is canceled. To cancel the mode without taking a shot, press the SPOT button again.

FLASH

Flash Strength

The flash on the IS-2 employs a new exposure control system that combines the advantages of both "flashmatic," used in compact cameras, and "auto flash", found in SLR cameras. Flashmatic emits a full-strength flash while automatically adjusting the aperture for proper exposure. This system is effective in most cases. However, subjects at extremely close range tend to be overexposed, and the background too dark, because the narrowest aperture setting has been selected. Auto flash varies the amount of light emitted by the flash, and sets the exposure by measuring reflected light. Depending on the background however, the wrong exposure for the main subject can be selected. For example, with a white background, the subject may appear too dark due to the level of reflected light received through the lens. The reverse is true for a dark background.

The IS-2 adjusts both the aperture and flash strength to give you perfect exposure every time, taking into account the effect of the background light and the distance to the subject.

Dual-Strobe Intelligent Flash

The flash of the IS-2 is distinguished by two emission tubes. One of the most important functions of a flash is to distribute light evenly throughout the frame. When a zoom lens is used, the area that can be lit by a single flash is determined by the wide-angle focal length. When telephoto is used, the light is wasted because the light is spread over a wide area. If this wasted light is concentrated on the picture area however, the working distance of the

flash will be increased. Solving this problem is crucial to effective telephoto-flash photography.

The zoom flash system found in some cameras is one solution to this problem. With this system, the distance between the xenon tube — which is the emission source of the flash — and the reflective material behind it is varied according to the focal length of the lens. When telephoto is used, the light from the flash is condensed more intensely. (The distance between the xenon tube and the condenser lens can be varied for the same result.)

So why does the IS-2 incorporate the dual-strobe system? Because the dual-strobe system can utilize the light more effectively while achieving more uniform lighting than the zoom flash system is capable of. The zoom flash system also cannot alter the actual shapes of the reflector and the condenser lens. In practice, these two factors greatly affect the even distribution and condensing intensity of light from the flash. The zoom flash sacrifices the effective use of the light's intensity for even distribution. To achieve both optimal condensing intensity and even distribution, Olympus developed the dual-strobe flash system with two sets of tubes and a reflective backing that are ideal for both wide-angle and telephoto photography. This makes a powerful, versatile flash with GN 20 (ISO 100 • m) / GN 66 (ISO 100 • ft) possible.

The lower tube is designed for telephoto photography and offers GN 20 (ISO 100 • m) / GN 66 (ISO 100 • ft). The upper tube is an intelligent variable-power flash offering GN 15–1.6 (ISO 100 • m) / GN 50–5.3 (ISO 100 • ft). When the flash strength should be less than GN 15 (ISO 100 • m) / GN 50

(ISO 100 • ft) in order to obtain natural-looking results, even if the lens is set at telephoto, the upper flash will automatically fire.

Even during macro photography, the flash light won't be obstructed by the tip of the lens since the intelligent variable-power flash is placed up and to the side of the camera. The flash is also capable of emitting minimal intensity for ideal macro photography.

Auto-S Flash

The Auto-S Flash mode includes a series of pre-flashes that reduces the phenomenon of red-eye, in addition to the same functions as the Auto Flash mode which prevent camera-shake and insufficient lighting by automatically firing in dimly lit and dark conditions when the flash is flipped up. The phenomenon of red-eye is when subject's eyes appear red in printed photographs. In this mode, the camera will start emitting approximately 20 low-power pre-flashes about a second before the regular flash.

This contracts pupils, which are wide open in the dark, significantly reducing red-eye. The pre-flashes do not decrease the power of the main flash. In addition, the red-eye reducing effect varies according to shooting conditions.

Fill-in Flash

Fill-in refers to the auxiliary light that "fills in" areas of the subject shadowed by the main light source. Even when the subject is backlit, the IS-2 can shoot it at the correct exposure using ESP metering or spot metering, however this may wash out the background. This happens because the difference in brightness between that of the subject and the background is too great. When the Fill-In Flash is used in such a cases, the subject is lit brightly by the flash. This minimizes the difference in brightness

between the subject and the background, allowing both to be shot clearly. This light is also reflected from the subject's eyes (catch light effect), making the picture lively.

In this mode, the flash fires no matter what light is available as long as the flash is flipped up. (Flash emission in well-lit conditions is called daylight synchro.)

Electronic Flash G40 (Optional)

The G40 is a dedicated flash for the IS-2 (GN 40, ISO 100 • m / GN 131, ISO 100 • ft). It is designed for professional flash photo-effects such as Bounce, Multi-Flash, and Follow-Synchro.

Bounce photography uses indirect lighting of subjects by reflecting the flash off the ceiling or wall. With straight flash photography a strong shadow often appears behind the subject. By bouncing the flash, you can obtain soft, well-balanced lighting of the entire subject. You can also use the built-in flash together with the G40 for additional affects.

Multi-flash emits the light several times in one exposure. With this flash mode, continuous movement, such as a golf swing, can be photographed sequentially in one frame. It's a multiple exposure with flash.

With Follow-Synchro mode, the flash fires at the final point of slow-synchro. For example, the tail-lights of a moving automobile can be captured on film.


When the IS-2 is equipped with the tele-converter lens (1.5X) or the wide-converter (0.8X), the built-in flash cannot be used. We recommend you use the G40 for such cases.

Note: In the Super Macro and 1:1 Macro modes, the Electronic Flash G40 does not fire except in the Manual Exposure mode.

Direct Flash



Multi Flash



Normal Slow-Synchro
(Curtain-1 Synchro)



Bounce (with simultaneous use of
the built-in flash)



Follow-Synchro
(Curtain-2 Synchro)



EFFECTS OF ZOOM AND ITS ADVANTAGES

In a zoom lens, the focal length is changed by moving part of the lens. In the case of the IS-2, any focal length between 35 mm and 135 mm can be selected.

- 35 mm wide-angle

Because the angle of view is wide and the depth of field is large, sharp photographs with enhanced perspective and contrast can be taken.

- 70 mm

With the lens zoomed to 70 mm, subjects appear two times closer than when the lens is positioned at 35 mm.

- 100 mm or more

When the lens is set to the maximum focal length of 135 mm, magnification is approximately four times greater than at 35 mm, for genuine telephoto photography. As the telephoto power is increased, the perspective narrows and the depth of field becomes more shallow. The result is that objects in front of and behind your subject are more likely to be out of focus. This can be used to interesting effect on snapshots and portraits.

Maximum telephoto lengths are particularly useful for taking pictures at sporting events and for nature photography, when you want to get closer to your subject without disturbing it.

IS/L LENS A-28 H.Q. CONVERTER 0.8X

28mm



75°



35mm



63°



70mm



34°



- The five pictures below are samples taken using the zoom lens. Notice the dimensions of the subject as the camera zooms in. The three pictures on the right were taken without changing the subject's size. Notice how the background and foreground tend to blur at increased focal lengths.
- Be sure to hold the camera firmly, as pictures tend to blur more easily at longer focal lengths.

Angle of view and depth of field

Angle of view is directly related to the focal depth of field (the distance in front of and behind the subject that the camera is able to bring into focus). The greater the angle of view (wide angle), the greater the depth of field. When the angle of view is narrow (telephoto), the depth of field decreases.

- The use of a converter lens (optional)
It is possible to attach a converter lens for an even wider angle of view, or for additional telephoto power.
 - Instead of 35 mm, a wide-angle converter (0.8X) enables you to reduce the camera's focal length to 28 mm.
 - Instead of 135 mm, a telephoto converter (1.5X) enables you to increase the camera's focal length to 200 mm.

IS/L LENS A-200 H.Q. CONVERTER 1.5X

135mm



18°

200mm



12°



35mm



70mm



135mm




AUTOFOCUS (AF)

■ Difficult Subjects for Autofocus to Lock On


Although the IS-2's autofocus can lock on virtually any subject, there are certain conditions, such as ①~③ shown below, where it may not be possible to obtain the correct focus. In the situations shown below in ④~⑥, autofocus may not lock on the correct subject even though the autofocus indicator lights and the shutter releases.

① Subjects with low contrast




- Use the focus lock by first focusing on something at the same distance as the subject you wish to take a picture of, and then aim at the subject. Or use the power focus to manually focus on the subject.

② Subjects that do not contain vertical lines




- Use the focus lock first while holding the camera vertically. Then switch the camera to the horizontal position to take the photograph. Or use the power focus to manually focus on the subject.

③ Subjects in excessively bright light




- Use the focus lock by first focusing on something at the same distance as the subject you wish to take a picture of, and then aim at the subject. Or use the power focus to manually focus on the subject.

④ Two subjects at different distances




- When the subject looks out-of-focus although the autofocus lamp lights, use the power focus to manually focus on the subject.

⑤ Subjects with repetitive patterns



- When the subject looks out-of-focus although the autofocus lamp lights, use the power focus to manually focus on the subject.

⑥ High-speed subjects at close range



- Focus on another subject at the desired camera-to-subject distance first. Switch the mode to power focus, and shoot the subject when it is at the distance set in advance.

EXPOSURE

■ Automatic Exposure Mode

Exposure refers to the amount of light which strikes the film, and is controlled by a combination of aperture size and shutter speed. The correct amount of light, called correct exposure, depends on the film speed (indicated on the film package, e.g. ISO 100 or ISO 200)

The automatic exposure function automatically sets the correct exposure. The IS-2 employs two types of automatic exposure modes: (1) programmed auto exposure, and (2) aperture-preferred auto exposure.

With programmed auto exposure, the camera automatically selects the most suitable combination of F stop and shutter speed for the existing lighting conditions. This lets you concentrate on composing your shot and releasing the shutter at just the right time.


With aperture-preferred auto, you select the desired F stop, and the camera automatically selects the correct shutter speed. Aperture-preferred auto allows greater manual control for more artistic freedom of expression and creativity.

■ Program Chart (Standard Photography Mode)

Following program chart is for 35mm wide-angle and 135mm telephoto focal lengths. According to the focal length, the camera's program itself changes. When the subject is brightly lit, the F stop and shutter speed changes simultaneously. When the lighting is darker, the aperture opens fully and the shutter speed changes to match it.

In the standard photography mode (refer to p. 12),


if the built-in flash has been flipped up, it will automatically fire in dark lighting conditions. The shutter speed will be fixed at 1/100-sec.



■ Program Chart (Portrait Mode)

The chart shown below is a program chart for portrait mode.

The shutter speed will automatically be adjusted up to 1/2000-sec. with the aperture fully opened. If the lighting then becomes brighter, the aperture will be adjusted to compensate. This is because with a larger (more open) aperture, the depth of field is reduced. That means that the farther the background is, the more out-of-focus it will be. At the same time, shutter speed is increased to prevent blurry pictures caused by shaking the camera.



■ Night Scene Mode

When shooting night scenes you may sometimes be disappointed with the result, usually because the camera's automatic exposure function works on a standard exposure ratio. In such situations a professional photographer would adjust for exposure compensation based on long experience, or select the manual shooting mode.

The IS-2's night scene mode will automatically adjust the exposure compensation for attractive night scene photography. For example, when shooting a subject with a night scene as its background, the use of the flash is often desirable. Should that be the case, the camera performs the most suitable exposure compensation for both the subject and the background. Since the selected shutter speed may be very slow (up to 4 seconds with ISO 100 or 15 seconds with ISO 25), the camera should be held firmly in position (with a tripod for example) to prevent blurring.

■ Sports Mode

This mode is ideal for capturing high-speed photo opportunities such as sports scenes and children at play. A fast shutter speed is automatically selected to "freeze" the action on film. However, the high shutter speed is not the only important feature of this mode. To shoot such high-speed action, excellent timing is essential to take the photo at just the right moment. This mode offers the optimal combination of continuous shooting and autofocus to maximize your timing for maximum results.

METERING THE AMOUNT OF LIGHT

■ Light Metering

Light metering can measure the brightness of the framed picture in various ways. The IS-2 employs three metering systems: (1) ESP light metering, (2) center-weighted average light metering, and (3) spot metering. The IS-2 allows you to select the light metering system most suitable in any photographic situation.

At the same time, the IS-2 uses TTL (through-the-lens) light metering to automatically measure the light that enters the lens. This allows you to obtain very accurate light metering that is not affected by changes in the distance between the subject and the camera.


■ Fuzzy Logic ESP (Electro-Selective Pattern) Light Metering (Exposure Mode P)

ESP light metering measures the brightness of the central portion and peripheral portion of the frame separately in order to determine the proper exposure. The calculation program used is based on programmed data to properly compensate for backlighting. ESP light metering is used automatically when in the P (Program) mode.

■ Center-Weighted Average Light Metering (Exposure Mode A or M)

Center-weighted average light metering is the most widely used light metering system (Fig. A). This system measures the light available throughout the frame with special emphasis on the center of the frame. When in A (Aperture-preferred) or M (Manual) mode, this light metering system is


automatically activated. When the contrast between bright and dark areas is not too extreme outside the center of the frame, this system offers excellent results.



■ Spot Metering

Spot metering (Fig. B) measures the brightness at the center of the frame only. Because this metering system calculates the correct exposure for only one point, it is convenient when the subject is backlit or the picture contains strong contrasts. When shooting a subject in front of an extremely bright background, you should use spot-metering on the subject's face. To properly expose white objects, use spot metering and then press the + side of the exposure compensation button. To properly expose black objects, use spot metering and then press the - side of the exposure compensation button.

Spot metering can be used in any of the P, A or M exposure modes.



EXPOSURE COMPENSATION

■ Fixed Proper Exposure

Proper exposure refers to the balance of light and dark in a photo. When shooting a black and white wall, the exposure will be based on the average ratio of black and white — thus the overall exposure is set for gray. This is technically called "fixed proper exposure." A good example of this is a subject with a strongly lit background. The reason the subject turns out dark is because there is more brightness than darkness in the frame. Therefore, the fixed proper exposure is based on the total level of light in the photo, which is significantly brighter than the subject. In the case of strong backlighting, the exposure needs to be adjusted to compensate for the excessive brightness.

Adjusting the exposure to accommodate lighting conditions is called exposure compensation. When ESP light metering is used, the camera automatically evaluates the lighting situation and compensates for the proper exposure, so manual exposure compensation is not needed.

■ Exposure Compensation

With the IS-2, ± 4 EV exposure compensation in $1/3$ EV steps is possible. + Compensation will make a subject appear brighter, while - compensation will make a subject appear darker. Under backlit conditions you'll want to make your subject appear brighter (+1 to +2EV). For shooting winter snow scenes, you may want adjust the exposure for additional definition (+2EV). Or, suppose your picture is composed of a black wall, (-2EV) compensation would most likely be appropriate.

FILM SPEED

■ Film Speed

Film speed is indicated on the back of film packages. ISO 100, ISO 200, and ISO 400 are the most common. High-speed film (ISO 400), as implied by its name, is for taking photos of fast-moving subjects in action shots, for example. However, there are also other advantages. With high-speed film, such as ISO 400, it is possible to take pictures in lower light. And the distance covered by the flash will be greater.

With this camera, we recommend the use of "DX" film cartridges: ISO 25, 32, 50, 100, 200, 400, 800, 1600, and 3200. In the case of non-DX-coded film, the camera will automatically be set to film speed ISO 32. Also, films with intermediate speeds such as ISO 64, 160, and 1000 are automatically set to the next lower speed. When using intermediate film, use the exposure compensation.

ISO 64:-0.3 EV; ISO 160:-0.7 EV;
ISO 1000:-0.3 EV

MACRO PHOTOGRAPHY

■ Zoom Macro

The IS-2 has an automatic macro function that enables you to shoot subjects as close as 0.6 m (2 ft) when the focal length is set from 35mm to 100mm. The autofocus and built-in flash can also be used with this function, which can fill the frame with an area of approx. 15x22 cm (5-7/8x8-11/16 in) at a working distance of 0.6m (2 ft) with the focal length set to 100mm. The picture area can be adjusted by changing the focal length and working distance. The range in which the zoom macro is effective is indicated on the lens barrel. So, if you want to shoot a subject closer than 1.2m (3.9 ft) when the lens is at a telephoto setting greater than 100mm, zoom out to a wide-angle setting to position the lens within the zoom macro range.

■ Super Macro

The Super Macro mode is ideal when you want to fill the frame with a small subject. In this mode, the focal length is fixed at 70mm, and shooting is possible as close as 0.39 m (15-3/8 in) to the subject. With this function, an area approx. 12 x 18 cm (4-3/4 x 7-1/16 in) can fill the entire frame, and the picture can be adjusted by changing the camera-to-subject distance. The autofocus and built-in flash can be used with this mode. To prevent blurry pictures caused by shaking the camera, use of the built-in flash is recommended. The camera can focus as far as infinity in this mode, so you'll never miss a photo opportunity.

■ **IS/L LENS A-LIFE SIZE MACRO H.Q. CONVERTER
f=13cm (Optional)**

This is a dedicated close-up converter that lets you capture life-size images of small subjects on film (when the focal length is 135mm), for genuine macro photography. When standard-size prints are made, the images become approx. 3 times bigger. The picture area can be changed between approx. 2.4 x 3.6 cm (life-size) and 9 x 13cm (15/16 x 1-7/16 in and 3-9/16 x 5-1/8 in). When the 1:1 Macro mode is engaged, the built-in flash will give perfect results in the Auto Flash mode. The camera automatically determines the working distance, which is one of the most difficult aspects of macro photography. The camera's autofocus system also takes care of fine focus adjustments. Now, anyone can perform advanced macro photography that would otherwise require a special flash unit and advanced photographic experience.

■ **IS/L LENS A- MACRO H.Q. CONVERTER
f=40cm (Optional)**

This is a close-up lens that lets you fill the frame with an area approx. 6 x 9 cm (2-3/8 x 3-9/16 in), about the size of an ordinary business card. This converter can be used with the Aperture-Preferred Auto Exposure mode and the Manual Flash mode. Autofocus also works when using this mode, making it ideal for macro photography beginners.

Super Macro



Converter f= 40cm



1:1 Macro f=13cm



■ Picture Area

Size sample	A4	A5	Post card	Cigarette pack								Working Distance (in)
Area (mm)	360X240	180X120	120X80	90X60	72X48	60X40	51X34	45X30	40X27	36X24		
(in)	14-3/16 x 9-7/16	7-1/16 x 4-3/4	4-3/4 x 3-1/8	3-9/16 x 2-3/8	2-13/16 x 1-7/8	2-3/8 x 1-9/16	2 x 1-5/16	1-3/4 x 1-3/16	1-9/16 x 1	1-7/16 x 15/16		
Magnification	0.1X	0.2X	0.3X	0.4X	0.5X	0.6X	0.7X	0.8X	0.9X	1X		
Zoom Macro	f=35mm											60~∞ (2-3/8"~∞)
	f=100mm											60~∞ (2-3/8"~∞)
Super Macro f=70mm												39~∞ (1-9/16"~∞)
Converter f=40cm												43-56 (1-11/16"-2-3/16")
1:1 Macro f=13cm												25-29 (1"-1-1/8")

PANORAMA PHOTOGRAPHY (OPTIONAL)

By mounting the optional IS/L PANORAMA ADAPTER inside the camera, panorama pictures can be taken. Zoom in and out with the adapter mounted to obtain various compositions. When the optional IS/L LENS A-28 H.Q. CONVERTER 0.8X is used with the adapter, wide-angle panorama photography is possible, adding extension and depth to pictures.



Picture area is shown with panorama marks as illustrated on the left.

Panorama marks

- When the adapter is mounted, the entire roll of film must be shot as panorama-format pictures,
- Panorama prints generally take longer to get processed than ordinary prints.
- Availability of Panorama-format film processing facilities varies according to area. Consult your local film processor or camera dealer for details.

ACCESSORIES (OPTIONAL)

IS/L LENS A-200
H.Q. CONVERTER
1.5X



IS/L LENS A-28
H.Q. CONVERTER
0.8X



IS/L LENS A-LIFE SIZE
MACRO H.Q.
CONVERTER f=13cm



IS/L LENS
A-MACRO H.Q.
CONVERTER
f=40cm



Electronic Flash
G40



Soft Case A



Grip Strap A




IS/L PANORAMA
ADAPTER



M-Remote Cord
1.2m/5m



Variable Dioptic
Adapter A



CARE AND STORAGE

CAUTIONS

- DO NOT EXPOSE THE CAMERA TO EXTREME HEAT (OVER 40°C/104°F) OR TO EXTREME COLD (BELOW -10°C/14°F).
- AVOID SUDDEN TEMPERATURE CHANGES AND HUMIDITY.
- DO NOT EXPOSE THE CAMERA TO STRONG MAGNETIC FIELDS.
- DO NOT APPLY EXCESSIVE FORCE TO THE CAMERA OR ITS CONTROLS.
- DO NOT TOUCH THE CONTACT POINTS INSIDE THE CAMERA.
- DO NOT USE ORGANIC SOLVENTS, THINNERS, OR BENZINE TO CLEAN THE CAMERA.
- AVOID STRONG IMPACTS CAUSED BY BUMPING OR DROPPING THE CAMERA.
- DO NOT EXPOSE THE CAMERA TO WATER, SUCH AS FROM RAIN.
- DO NOT EXPOSE THE CAMERA TO DUST AND SAND.

WARNING

- NEVER ATTEMPT TO DISASSEMBLE THE CAMERA; IT CONTAINS A HIGH-VOLTAGE CIRCUIT.

In case of malfunction, consult your nearest Olympus dealer or Olympus service center.

BATTERY HANDLING

NOTES

- Do not mix different types of batteries or new and old batteries.
- When the camera is not used for an extended period of time, remove the batteries.
- Keep spare batteries on hand when going on a long trip or to a cold area.
- Sweat, oil, and so on can prevent a battery's terminals from making electrical contact. To avoid this, wipe both terminals before loading batteries.

WARNINGS

- NEVER TRY TO DISASSEMBLE, RECHARGE, OR SHORT CIRCUIT BATTERIES. NEVER EXPOSE BATTERIES TO EXCESSIVE HEAT OR OPEN FLAMES.
- KEEP THE BATTERIES OUT OF THE REACH OF CHILDREN. IF A CHILD SWALLOWS A BATTERY, CONTACT A DOCTOR IMMEDIATELY.
- USE TWO 3V LITHIUM BATTERIES (CR123A OR DL123A). NEVER TRY TO DISASSEMBLE OR MODIFY ANY BATTERY OR BATTERY PACK FOR USE IN THIS CAMERA.

TROUBLESHOOTING

Operating Problems

Symptom	Cause	Remedy	See
The camera does not work.	<ul style="list-style-type: none"> ① The power is OFF. ② The batteries are loaded incorrectly. ③ The batteries are exhausted. ④ The batteries are temporarily unable to function. ⑤ The loaded film has been rewound. ⑥ The film is incorrectly loaded. 	<ul style="list-style-type: none"> ① Set the power switch to ON. ② Reload the batteries correctly. ③ Replace the batteries with new ones. ④ Keep the camera warm while using it. ⑤ Load new film. ⑥ Reload the film. 	<p>p.16 p.8 p.9</p> <p>p.19 p.15</p>
The displays turn off suddenly.	<ul style="list-style-type: none"> ① The LCD panel and viewfinder displays turn off after approx. 30 sec. (5 min. when the flash is flipped up) if the camera is not used. 	<ul style="list-style-type: none"> ① Press the shutter release button halfway to turn on the displays. 	p.16
The shutter speed and aperture setting blink.	<ul style="list-style-type: none"> ① When the light metering function of the camera does not work correctly because it's too dark, these indicators start blinking. In the Manual Exposure mode, ± also blinks. ② If the camera-to-subject distance is too great when the flash is used, they start blinking 	<ul style="list-style-type: none"> ① Use the flash. ② Move the camera closer to the subject. 	<p>p.23</p> <p>p.24</p>
The subject cannot be focused.	<ul style="list-style-type: none"> ① When the subject is moving too fast, the camera is being shaken, or the subject is difficult for autofocus to lock on (refer to p.57), the autofocus may not work. ② The subject is closer than the camera's minimum working distance (0.6 m/2 ft with 35 ~ 100mm or less than 1.2m/3.9ft with 100~. 135mm) ③ When the PF mode is engaged, autofocus will not operate even though the shutter release button is pressed. 	<ul style="list-style-type: none"> ① Focus on the subject by using the power focus, or by first focusing on something at the same distance as the subject. ② Use the Super Macro mode. ③ Cancel the PF mode. 	<p>p.57</p> <p>p.30</p> <p>p.50</p>

Symptom	Cause	Remedy	See
The camera doesn't focus on the subject even though the AF illuminator lights.	① The autofocus may not work when the subject is out of the AF illuminator's working distance (approx. 1.2 ~ 6 m/3.9 ~ 20 ft) or when the subject has low contrast (blue or black).	① Use the power focus, or move the camera closer to the subject.	p.29
The shutter doesn't release even when the shutter release button is pressed.	① The subject is not in focus. ② The rewound film is still loaded.	① Make sure the subject is in focus and the autofocus indicator in the viewfinder lights. ② Remove the film.	p.18 p.19
The flash doesn't fire	①  doesn't light in the viewfinder. ② The shutter speed is set at 1/1 25-sec. or faster. ③ The flash has been used repeatedly.	① Press the shutter release button halfway to light  . ② Set the shutter speed at 1/100-sec. or slower. ③ Wait until  lights.	p.23 p.48 p.23

Problems with Printed Pictures

Symptom	Cause	Remedy	See
The subjects' eyes appear red in printed pictures.	① This "red-eye phenomenon" occurs with all cameras when a flash is used. It is caused by light from the flash reflecting off retina at the back of the eye. Red-eye varies depending on the individual and the shooting conditions such as ambient lighting. It is also more likely to occur when using 135mm telephoto than when using wide-angle focal lengths.	① Use the Auto-S Flash mode to significantly reduce red-eye phenomenon.	p.25
The subject was within the frame of the viewfinder, but its edges are missing on the print.	① When a negative is enlarged, sometimes the edge of the frame is not printed.	① Leave some room on the edges of the frame when you compose your shots.	
The film is scratched	① Film particles have accumulated along the path that the film follows as it is wound due to extended use of the camera	① Clean the inside of the camera.	
The picture is out of focus.	① The camera moved when the shutter release button was pressed. ② The viewfinder's autofocus frame was not positioned on the subject.	① Hold the camera correctly, and press the shutter release button gently. ② Position the autofocus frame on the subject, or use the focus lock.	p.10 p.20
The picture is too dark.	① The subject was out of the working range of the flash. ② The subject was backlit.	① Shoot within the working range of the flash. ② Set the flash to Fill-In mode.	p.24 p.26

QUESTIONS AND ANSWERS

Q: How long will the batteries last?

A: Two new 3V lithium batteries will last for roughly 25 rolls of 24-exposure film on which the flash was used on half of all the shots (determined under Olympus test conditions). If you do not use the flash and zoom very often, the batteries will last much longer.

Q: How should I store the camera?

A: Cameras are susceptible to damage caused by dust, moisture, and salt. Wipe and dry the camera thoroughly before storing it. After using it at the beach, wipe it with a cloth that has been moistened with fresh water and then wrung out. Do not use insecticides.

Q: Can the M-Quartz Remote Controller 1 be used?

A: No, it cannot.

Q: When does the camera measure and set the exposure?

A: When the shutter release button is pressed halfway, the camera measures both the exposure and the focus and then locks them as long as the shutter release button remains halfway depressed. In the Spot Metering mode, the exposure is locked when the spot button is pressed.

Q: How should I clean the lens?

A: Wipe the lens gently with lens cleaning tissue that has been moistened with a small amount of lens cleaning fluid.

SPECIFICATIONS

Type: Fully automatic 35mm autofocus single-lens reflex camera with built-in 35mm ~ 135mm zoom lens.

Film format: 35mm standard DX-coded film (24 X 36mm)

Lens: Olympus lens (filter available, 49mm filter diameter) 35mm ~ 135mm F4.5 ~ 5.6, 16 elements in 15 groups (5-group zoom construction) with extraordinary dispersion (ED) glass at third element in the first zoom lens group.

Shutter: Electronic control system vertical focal plain shutter. Shutter speed 1/2000-sec. ~ 15-sec. bulb.

Focusing: TTL phase-difference detection system autofocus with focus lock, AF illuminator automatically lights up in low light. Manual focusing available (power focus). Focusing range — 0.6m (2 ft) ~ ∞ at 35 ~ 100mm; 1.2m (3.9 ft) ~ ∞ at 100mm or larger; 0.39m (1.3 ft) ~ ∞ in Super Macro mode.

Viewfinder: Single-lens reflex system, magnification ratio 0.75 (at 50mm). Finder view-field — 85% of actual view-field.

Viewfinder information: Autofocus frame, spot frame, panorama marks, autofocus indicator, flash indicator (to be used as flash warning), shutter speed, aperture setting, spot metering, macro, exposure compensation (manual exposure).

Light metering system: TTL light metering system — Fuzzy logic ESP light metering, center-weighted average light metering, spot metering.

Exposure modes: (1) Program AE (Standard, Sports, Portrait, Night-Scene), (2) Aperture-preferred AE, (3) Manual exposure.

Exposure compensation: ±4 EV compensation possible (1/3 EV step).

Exposure counter: Progressive type, displayed on LCD panel.

Film speed range: Automatic setting with DX-coded film (ISO 25, 32, 50, 100, 200, 400, 800, 1600, 3200. Other intermediate film speeds will be automatically set for next lower speed).

Film loading: Automatic loading (automatically advances to first frame when camera back is closed).

Film advance: Automatic film winding, consecutive winding max. 2.3 frames/sec. (in PF mode, under Olympus test conditions), double exposure possible.

Film rewind: Automatic film rewind (automatic rewind activated at end of film, automatic rewind stop). Rewind is possible at any point with rewind button.

Selftimer: Electronic selftimer with 12-sec. delay.

Flash: Built-in IVP (Intelligent Variable-Power) flash system with dual light emitting tubes. Manual activating system, recycling time of about 3.5 sec. (at normal temperature). Light emission: Automatic — ISO 100 • m of GN 20 / ISO 100 • ft of GN 66, Manual — ISO 100-m of GN 15/ISO 100 • ft of GN 50

Flash range: Wide — 0.6 ~ 4.6 m (2 ~ 15.1 ft), Tele — 1.2 ~ 5 m (3.9 ~ 16.4 ft) with ISO 100 negative color film; Wide — 0.6 ~ 9.2 m (2 ~ 30.2 ft), Tele — 1.2 ~ 10 m (3.9 ~ 32.8 ft) with ISO 400 negative color film, Flash available in Super Macro mode.

Flash modes, Auto (automatic flash activation in low-light), Auto-S (red-eye reducing, same as Auto otherwise), Fill-In (forced activation), Manual.

Battery check: Displayed on LCD panel.

Power source: Two 3V lithium batteries (CR123A or DL123A) (replaceable).

Dimensions: 117(W) X 91 (H) X 155(D) mm (4-5/8X3-9/16X6-1/8 in) (excluding protrusions).

Weight: 890 g (31.4 oz) (without batteries).

SPECIFICATIONS ARE SUBJECT TO CHANGE WITHOUT ANY NOTICE OR OBLIGATION ON THE PART OF THE MANUFACTURER.

OLYMPUS®

OLYMPUS OPTICAL CO., LTD.

San-Ei Building, 22-2, Nishi Shinjuku 1 -chome, Shinjuku-ku, Tokyo, Japan. Tel. 03-3340-2211

OLYMPUS CORPORATION

Crossways Park, Woodbury, New York 11797-2087, U.S.A. Tel. 516-364-3000

OLYMPUS OPTICAL CO.(EUROPA) GMBH

Postfach 104908, Wendenstrasse 14-16, 2000 Hamburg 1, Germany. Tel. 040-23773-0

OLYMPUS OPTICAL CO. (U.K) LTD.

2-8 Honduras Street, London EC1Y 0TX, United Kingdom. Tel. 071-253-2772